



SIGNAL	ROUTE	DESTINATION	IND	TYPE	SIGNAL	ROUTE	DESTINATION	IND	TYPE
114	114	DOWN MAIN	LHJR W 106(M)AR	---	126	126	DOWN MAIN	---	---
116	116	UP MAIN	RHJR W 108(M)BR	---	128	128	UP MAIN	---	---