



\*1 CONTINUED FROM PART 5/9

CONTINUED ON PART 7/9

SEE NOTE 1

NOTE 1: NO OVERHEAD SYMBOL

POINTS No.	POINTS TYPE	HANDLE INDEX
333	WB&S 84M	AH
338	WB&S 84M	AD
339	WB&S 84M	AE
348	WB&S 84M	AF
387	WB&S 084M	AP

SIGNAL	ROUTE	DESTINATION	IND	TYPE
524	IMA	STAGING ROAD 2	-	SRI
	ISA	STAGING ROAD 2	S2	SRI
	IMB	STAGING ROAD 1	-	SRI
	ISB	STAGING ROAD 1	S1	SRI

SIGNAL	ROUTE	DESTINATION	IND	TYPE
210	ISA	ROAD 8	8	SRI
	ISB	ROAD 7	7	SRI
	ISC	ROAD 6	6	SRI
	ISD	ROAD 5	5	SRI
216	ISA	ROAD 10	10	SRI
	ISB	ROAD 9	9	SRI
218	ISA	ROAD 5	5	SRI
	ISB	THROUGH ROAD 1	T1	SRI
219	IMA	DOWN MAIN	-	-
	ISA	DOWN MAIN	DM	SRI
	IMB	UP MAIN	-	-
	ISB	UP MAIN	UM	SRI
221	IMA	DOWN MAIN	-	-
	ISA	DOWN MAIN	DM	SRI
	ISC	THROUGH ROAD 1	T1	SRI
236	ISA	THROUGH ROAD 1	T1	SRI
	B	UP MAIN	GREEN LIGHT	-
	ISB	UP MAIN	UM	SRI

ARTC  
 ENFIELD  
 PART 6 of 9  
 PRODUCED BY SIEMENS RAIL AUTOMATION VER:08122014