



ALLAWAH

HURSTVILLE

PENSHURST

921	(S)A DN LOCAL	DL
	(M)B UP LOCAL	-
	(S)B UP LOCAL	UL

909	(M)A DN MAIN	-	909(S)
	(S)A DN MAIN	DM	A DMUM B
	(M)B UP MAIN	-	
	(S)B UP MAIN	UM	

911	(M)A DN LOCAL	-	911(S)
	(S)A DN LOCAL	DL	A DLUL B
	(M)B UP LOCAL	-	
	(S)B UP LOCAL	UL	

929	(M)A DOWN MAIN	D
	(S)A DOWN MAIN	DM
	(M)B UP MAIN	-
	(S)B UP MAIN	UM
	(M)C UP LOCAL	L
	(S)C UP LOCAL	UL

931	(M)A DOWN MAIN	D
	(S)A DOWN MAIN	DM
	(M)B UP MAIN	U
	(S)B UP MAIN	UM
	(M)C UP LOCAL	L
	(S)C UP LOCAL	UL

933	(M)A UP LOCAL	-
	(S)A UP LOCAL	UL
	(S)B STABLING ROAD	SR

936	(M)A DN LOCAL No.2 PLAT	2
	(S)A DN LOCAL	DL
	(M)B UP MAIN No.3 PLAT	3
	(S)B UP MAIN	UM
	(M)C DN MAIN No.4 PLAT	-
	(S)C DN MAIN	DM

938	(M)A DN LOCAL	-	938(S)
	(S)A DN LOCAL	DL	A DLUM B
	(M)B UP MAIN	-	
	(S)B UP MAIN	UM	

940	(M)A UP LOCAL	-	940(S)
	(S)A UP LOCAL	UL	A ULDL B C
	(M)B DN LOCAL No.2 PLAT	2	
	(S)B DN LOCAL	DL	
	(M)C UP MAIN No.3 PLAT	3	
	(S)C UP MAIN	UM	

943	(M)A DOWN MAIN	-
	(S)A DOWN MAIN	DM
	(M)B UP MAIN	-
	(S)B UP MAIN	UM

952	(M)A UP MAIN	-
	(S)A UP MAIN	UM
	(M)B DOWN MAIN	-
	(S)B DOWN MAIN	DM

942	(S)A UP ILLAWARRA LOCAL	UL
	(S)B DN ILLAWARRA LOCAL	DL
	(S)C UP ILLAWARRA MAIN	UM

945	(M)A DOWN MAIN	D
	(S)A DOWN MAIN	UM
	(M)B UP MAIN	U
	(S)B UP MAIN	UM

948	(M)A UP LOCAL	-
	(S)A UP LOCAL	UL
	(M)B UP MAIN	-
	(S)B UP MAIN	UM