



NOTE: NOT ALL SIGNALLING SHOWN FOR THE SUBURBAN AND MAIN LINES

<p>RELIANCE RAIL</p> <p>AUBURN MAINTENANCE FACILITY DRIVERS DIAGRAM STAGES 1 & 2 (SHEET 1 OF 5) PRODUCED BY ANSALDO STS</p>
--