



NOTE: NOT ALL SIGNALLING SHOWN FOR THE SUBURBAN AND MAIN LINES

<p><b>RELIANCE RAIL</b></p> <p>AUBURN MAINTENANCE FACILITY          DRIVERS DIAGRAM          STAGES 1 &amp; 2          (SHEET 5 OF 5)          PRODUCED BY ANSALDO STS</p>
<p>VER16032010</p>