


SIGNAL	ROUTE	TYPE	DESTINATION	IND'N	TYPE
GF 77	77	M	DOWN REFUGE	-	-
	77U	S	DOWN REFUGE	DR	SRI
	74	M	DOWN MAIN	-	-
	74U	S	DOWN MAIN	DM	SRI

POINTS No.	POINTS TYPE	EMERGENCY OPERATION			LOCATION	INSCRIPTION
		TYPE	EOL INDEX	MACHINE INDEX		
201A	WBS D84M MKIII	EOL KEY	A-E		GF111	GOSFORD EOL + 201A POINTS MOTOR
201B	WBS D84M MKIII	EOL KEY	A-E		GF111	GOSFORD EOL + 201B POINTS MOTOR
202A	WBS D84M MKIII	EOL KEY	A-F		GF111	GOSFORD EOL + 202A POINTS MOTOR
202B	WBS D84M MKIII	EOL KEY	A-F		GF111	GOSFORD EOL + 202B POINTS MOTOR

SIGNAL	ROUTE	TYPE	DESTINATION	IND'N	TYPE
GF112	114	M	UP REFUGE	-	-
	114U	S	UP REFUGE	UR	SRI
	112	M	UP MAIN	-	-
	112U	S	UP MAIN	UM	SRI



Transport for NSW
WOY WOY (EXCL) - GOSFORD (INCL)
SIGNALLING ARRANGEMENT
 WN 04, 05 & 06- 2015 VER 01102014