

LEGEND


* RELEASED BY OPERATORS KEY

PUSHBUTTONS

∕ TEST, EMERGENCY SWITCH,
MANUAL OP. SWITCH,
SHUNTER'S PUSH BUTTON

@ TEST, EMERGENCY SWITCH,
MANUAL OP. SWITCH


'PUSHBUTTON




INSCRIPTION ON INSIDE OF DOOR:

* INSERT OPERATORS KEY
 * DEPRESS 'INDICATOR CANCEL' BUTTON FOR 2 SEC.
 * POINTS FREE INDR. WILL FLASH UNTIL POINTS BECOME FREE AFTER 2 MINUTES.
 * WHEN A STEADY POINTS FREE INDR. IS ILLUMINATED
 * (FOR MAIN LINE) - DEPRESS 'MAIN CLEAR' BUTTON
 * (FOR LOOP LINE) - DEPRESS 'LOOP CLEAR' BUTTON
 * THE CROSSING WILL COMMENCE OPERATION
 * INDICATOR WILL CLEAR AFTER 15 SECS.

**IVANHOE
CROSSING LOOP**



INSCRIPTION ON INSIDE OF DOOR:
 TO CLEAR INDICATOR
 PRESS CLEAR BUTTON, ONLY
 WHEN TRAIN READY TO DEPART.
 THE INDICATOR WILL CLEAR
 AFTER 15 SECONDS.
 TO CANCEL INDICATOR
 PRESS CANCEL BUTTON.
 THE FLASHING LIGHTS WILL
 STOP AFTER 2 MINUTES.



ARTC - DRIVERS DIAGRAM

IVANHOE

V1.0

IVANHOE DD.dwg

IVANHOE DD.dwg

FRAME C
 RELEASED BY OPERATORS KEY